

YSF WiRES-X Unintended Node Switching

Category: Hotspots, WiRES-X

August 9, 2019

A problem exists with YSF/MMDVM hotspots bridging to WiRES-X rooms. Here's what happens.

A user has a hotspot and accesses it using a Fusion HT. They use the WiRES-X control mode to change the hotspot to different YSF Reflectors. Let's say the user wants to access MNWis (Room #21,493):

- They enter the number of the YSF Reflector, "US MNWis 21493", which is 37,624. The hotspot switches to US MNWis 21493 which is bridged to WiRES-X Room # 21,493.
- The user leaves their radio in the WiRES-X control mode. They hear stations, but when they talk, nobody answers and nobody is talking.

Here's what happened: When they keyed up to transmit, their radio sent a command to switch to Room #37,624. The Wires-X node that was previously connected to #21,493 now connects to #37,624 which belongs to a very nice gentleman in France.

How does this happen?

The Fusion transmitted data includes callsign fields CSD1, CSD2, and others. We're interested in CSD1. This 10-byte field contains two items: The room number of the connection and; The TxID or DP-ID of the radio. A typical CSD1 looks like 21493F0yxh where 21493 is the room number and F0yxh is the DP-ID. The '21493' in this field will cause a Wires-X node to switch to that room.

When the radio IS NOT in Wires-X control mode, the CSD1 field will be: '*****F0yxh' and no switch will be made.

Bottom line:

DON'T USE WiRES-X control mode to talk through a hotspot or MMDVM!

Workarounds and fixes: (Updated 23-Aug-2019)

Node operators who are experiencing this problem should use the WiRES-X block feature to prevent the node from switching to the room that has the YSF reflector number.

For example: Assume that our node connects to MNWis, Room # 21,493. Our node also provides bridging to "YSF MNWis 21493" which is # 37,624.

- In the View->Node-Info(N) window press "Add".
- In the "Input ID" dialog box enter the YSF reflector number. In our example this is "37624".
- Press "OK" then "Close".
- When a station using the YSF bridge still has WiRES-X control mode enabled accesses the node, the command to switch rooms will be rejected by the WiRES-X software. The software will indicate a rejected attempt to switch rooms.

As an alternative, set the node so that connection changes are not allowed.

- File->Settings->Call Settings->Uncheck "Round Room Connection".
- Un check "Accept calls while in Round Room QS0.
- Check "Return to Room"
- Fill in the WiRES-X room number. Example: 21493.

YSF server side solutions:

I maintain a version of YSF Reflector that has filters to prevent hotspots causing problems with WiRES-X nodes. My first step is to drop all packets that contain an incorrect WiRES-X room number. Eventually I plan to replace the first 5 bytes of CSD1 with '*****'. This last step is difficult to do because it requires the reflector to decode the data, modify it, then recompute the CRC. This also involves working with the interleaving and forward error correction. It is obviously easier to just drop the packets, but that may confuse people on the YSF side since nobody on the WiRES-X side will hear them.

If you are interested in running the enhanced YSF Reflector software that will fix this problem at some point, please contact me privately.

73,

Chris, K9EQ

WiRES-X Automation

Category: Automation, Projects, WiRES-X

August 9, 2019

Yaesu does not provide a mechanism that allows the WiRES-X software to be controlled by another program, i.e., having another program switch to a certain Room when a net starts.

Windows does, however, permit another program to send events to a program. Each window, menu item, and dialog in a Windows program has a unique identifier. It is possible to use these identifiers to send "message" to the WiRES-X software.

The WiRES-X Automation Project's purpose is to bring together people who are interested in developing this technology and sharing their results.

To get things going, here are two mechanisms for automating WiRES-X:

1. AutoIT: <http://www.autoitscript.com>
2. Python – an excellent programming language found at python.org

Dave, N9TOW, provided the following information:

Packages I have installed on my WiresX system.

```
C:\Users\WiresX>pip list
comtypes (1.1.3)
pip (9.0.1)
pypiwin32 (220)
pywinauto (0.6.3)
setuptools (28.8.0)
six (1.10.0)
https://github.com/pywinauto/pywinauto
```

To install

```
pip install -U pywinauto
```

Script that executes changing channels on WiresX app

```
import time
from pywinauto import Application
    app = Application().connect(path="C:\Program Files
(x86)\YAESUMUSEN\WIRES-X\wires-X.exe")
app.WiresX.menu_select("Connect(C)->Connect To(T)")
time.sleep(1.5)
app.InputID.Edit.set_edit_text("21493")
```

```
time.sleep(.5)
app.InputID.OK.click()
time.sleep(4)
dialogs = app.windows()
##app.Dialog.CloseButton.click()
```

Python Program

Bill, W9LBR, developed a Python program that runs on the WiRES-X computer. [The software has been updated as of 12-Feb-2024. See more here.](#)

This is from his description:

WXscheduler.pyw is a Python 3 program that automates certain aspects of

Wires-X Room/Node connections according to a userdefined schedule.

To that end WXscheduler.pyw must be run on the same Windows PC that hosts the Wires-X application controlling either an HRI-200 or

a USB connected radio that supports PDN operation.

Schedulable operations:

- Connect
- Disconnect
- SetUnlimitedTOT
- SetTimeoutTOT
- Restart Wires-X App

Manual operation: Button that causes a Force Disconnect

Bonus operation: Displays Last Heard information that the Wires-X app

updates once a minute. Converting Lat/Lon into Grid Square if available.

A zip file containing instructions and the Python program is available at WXScheduler.

Update History

2 June 2023 v1.3 updates: – Last Heard now displays FT5-D, FTM-200, and FTM-500 correctly – Desktop\Wires-X_Last_Heard.html now generated to be viewed with PC browser

12 Feb 2022 updates: – Corrected grid square rendering of GPS coordinates as displayed in the Last Heard frame – version (v1.2) now displayed in main window title

5 Feb 2022 minor updates: – Fixed Last Heard display of recently manufactured FT70-D radios – WXScheduler.txt is now in DOS format, making it easier to read with Notepad 2022 version of WXScheduler.pyw – A scheduled event now performs multiple actions – Added File->Settings->Call settings actions – Fixed issue when Wires-X App is minimized – Fixed issue when Wires-X Settings window left open

Mobile WiRES-X Nodes

Category: Fusion,Hotspots,WiRES-X

August 9, 2019

FT2D Can Now Be Used As Mobile Node